


DOUBLE VALVE

ES Válvula Doble DE Ventil, doppelt wirkend
 IT Valvola Doppia PT Válvula Dupla FR Double Valve

● Cad Insertion Point

VD



Ref.	A	B	C	E	H
VD.080512	8	5	12	4	7
VD.100612	10	6	12	5	7
VD.120812	12	8	12	7	7
VD.161020	16	10	20	9	12

Installation Guidelines

Consejos de Instalación · Richtlinien zur Installation · Consigli di Installazione · Instruções de Instalação · Mode d'Installation

